

Acer Chromebook Spin 11 R751T/ R751TN

LIFECYCLE EXTENSION GUIDE

Self-Repair 1-1

Disassembly Procedures 1-2

Troubleshooting 1-24

FRU (Field Replaceable Unit) List 1-28

Check for updates yourself. 1-31

Factory reset your Chromebook. 1-32

Self-Repair

This chapter highlights the limited self-repair capabilities of the product.

Prior performing self-repair, familiarize yourself with the Safety Guidelines and Recommended Equipment sections first as described in the chapter "[Disassembly Procedures](#)".

Depending on model, the following key components are eligible for self-repair (if applicable);

- Battery pack
- HDD / SSD module
- DIMM module(s)
- WLAN module
- LTE module

If a particular key component is listed and thus would be eligible for self-repair, but is not described in the "[Disassembly Procedures](#)" section, then this component is either not present on the respective model, or it is present but embedded on the motherboard and therefore not eligible for self-repair.

⇒ **NOTE:**

Do not attempt to replace other components than those listed above.

⇒ **NOTE:**

For replacement parts, always use only Acer certified components in order to safeguard quality, optimum system performance, stability and reliability of the product.

⇒ **NOTE:**

Any damage to the product that occur during self-repair, or which has occurred as a result of a careless or unsuccessful self-repair attempt, is not covered by the standard product warranty.

Software Recovery

This product has embedded software recovery tools which can be used to either perform a partial or full software recovery, but also to create a Factory Default recovery media.

For more information about the software recovery options, how to perform a software recovery or creating a Factory Default recovery media, please refer to the chapter "Recovery" which is available in the User Manual of the product.

⇒ **NOTE:**

In the event of not being able to create a Factory Default recovery media, it is possible to obtain a copy of the recovery media through Acer Customer Service (<http://www.acer.com/support>)

This is not a free of charge service.

Disassembly Procedures

Safety Guidelines

This chapter contains step by step procedures on how to remove and de-install components from the computer. Use the following safety guidelines to ensure your personal safety. Each procedure included in this chapter assumes that you are preparing your computer for recycling and disposal. **By performing any of these procedures you acknowledge that any remaining warranty applicable to your computer will be voided. Before you start any of the procedures in this chapter, make sure to read the following safety guidelines and the respective instructions within the chapter.**

CAUTION!

- Turn off your computer and disconnect all power sources before opening the computer cover or panels.
- To avoid electrostatic discharge, ground yourself by using a wrist grounding strap or by periodically touching an unpainted metal surface at the same time as touching a connector on the back of the computer.
- Take off any metal objects on your arms or fingers such as bracelets, rings or watches and make sure your hands are completely dry. Even if your unit is unplugged, there may still be some remaining electric charge.
- If a component does not come out easily, do not forcefully remove it. Instead, check that you are removing it correctly and that no wires or other parts are in the way.
- When you disconnect a cable, pull on its connector or on its pull-tab, not on the cable itself. Some cables have connectors with locking tabs; if you are disconnecting this type of cable, press in on the locking tabs before you disconnect the cable.

Recommended Equipment

The following equipment are recommended to do the following maintenance procedures:

- Wrist grounding strap and conductive mat
- Philips screwdriver
- Plastic tweezers
- Flat plastic pry

WEEE Annex VII Component

These components are classified as requiring selective treatment:

- Battery pack
- WLAN module
- Touchpad module
- Mainboard
- USB board
- LCD panel

Pre-disassembly Instructions

Do the following prior to starting any maintenance procedures:

1. Place the system on a stable work surface.
2. Remove AC adapter (A) from the system and peripherals (Figure 1-1).
3. Remove the SD card from the SD card slot (B) (Figure 1-1).
4. Remove all cables from system.




Figure 1-1. AC Adapter Outlet & SD Card Removal

⇒ **NOTE:**

Make sure the system is completely powered off.

Base Cover Removal

1. Remove twelve (12) screws from the base cover ([Figure 1-2](#)).



Figure 1-2. Base Cover Removal

2. Using a flat headed tool, carefully pry open the base cover starting from the gap between the left LCD hinge compartment and the base cover ([Figure 1-3](#)).



Figure 1-3. Base Cover Removal

3. Continue prying open the base cover from the gap between the right LCD hinge compartment and the base cover (Figure 1-4).



Figure 1-4. Base Cover Removal

4. Remove the base cover from the system (Figure 1-5).



Figure 1-5. Base Cover Removal

Battery Pack Removal

Prerequisite:

Base Cover Removal

1. Find the battery (A) on the top assembly (Figure 1-6).
2. Disconnect the battery cable (B) from the mainboard connector (C) (Figure 1-6).




Figure 1-6. Battery Pack Removal

3. Remove the battery pack from the system (Figure 1-7).




Figure 1-7. Battery Pack Removal

+ IMPORTANT:

Follow local regulations for battery disposal.

WLAN (Wireless Local Area Network) Module Removal

Prerequisite:

Battery Pack Removal

1. Find the WLAN module (B) on the top assembly (Figure 1-8).




Figure 1-8. Component Location

2. Disconnect WLAN antenna cables (A) from the WLAN module (Figure 1-9).
3. Remove one (1) screw (C) securing the WLAN module in place (Figure 1-9).




Figure 1-9. WLAN Module Removal

4. Remove the WLAN module (B) from the mainboard connector (D) (Figure 1-10).



Figure 1-10. WLAN Module Removal

Touchpad Module Removal

Prerequisite:

Battery Pack Removal

1. Find the touchpad module (E) on the top assembly. Refer to [Figure 1-8](#).
2. Remove the adhesive tape (F) from the touchpad connector ([Figure 1-11](#)).




Figure 1-11. Touchpad Tape Removal

3. Disconnect the touchpad FPC (B) from the touchpad connector (A) and the mainboard connector (C) then remove the touchpad FPC from the top assembly ([Figure 1-12](#)).
4. Remove four (4) screws (D) securing the touchpad module in place ([Figure 1-12](#)).




Figure 1-12. Touchpad FPC Removal

5. Remove the touchpad module from the top assembly (Figure 1-13).




Figure 1-13. Touchpad Module Removal

⚠ CAUTION:

Touchpad FPC (Flexible Printed Circuit) can be damaged if removed while the mainboard connector and the touchpad connector are locked.

LCD Module Removal

Prerequisite:

Battery Pack Removal

1. Disconnect the WLAN antennas from the WLAN module (A) (Figure 1-14).
2. Disconnect the G-sensor cable from the mainboard connector (B) (Figure 1-14).
3. Disconnect the digitizer cable from the mainboard connector (C) (Figure 1-14).
4. Disconnect the eDP cable from the mainboard connector (D) (Figure 1-14).
5. Unthread all cables from the cable guides (Figure 1-14).




Figure 1-14. LCD Module Removal

6. Place the system on a flat surface and open the LCD module (E) as shown in [Figure 1-15](#).
7. Remove four (4) screws securing the LCD module in place ([Figure 1-15](#)).



Figure 1-15. LCD Module Removal

8. Lift and remove the LCD module away from the top assembly ([Figure 1-16](#)).



Figure 1-16. LCD Module Removal

⚠ CAUTION:

Make sure all cables and antennas are unthread from the cable guides to avoid damage removal.

Mainboard Removal

Prerequisite:

[LCD Module Removal](#) and
[WLAN \(Wireless Local Area Network\) Module Removal](#)

1. Find the mainboard (D) on the top assembly. Refer to [Figure 1-8](#).
2. Remove the adhesive tape (I) from the keyboard connector ([Figure 1-17](#)).




Figure 1-17. Keyboard Connector Tape Removal

3. Disconnect the 30-pin USB board FPC from the mainboard connector (B). Refer to [Figure 1-18](#).
4. Disconnect the 40-pin USB board FPC from the mainboard connector (C). Refer to [Figure 1-18](#).
5. Disconnect the second camera module cable from the mainboard connector (E). Refer to [Figure 1-18](#).
6. Disconnect the keyboard FPC from the mainboard connector (A). Refer to [Figure 1-18](#).
7. Disconnect the touchpad FPC from the mainboard connector (F). Refer to [Figure 1-18](#).
8. Disconnect the speaker cable from the mainboard connector (G). Refer to [Figure 1-18](#).

⚠ CAUTION:

Make sure all cables and FPCs are disconnected from the connectors on the mainboard to avoid damage during removal.

9. Remove four (4) screws (H) securing the mainboard in place ([Figure 1-18](#)).




Figure 1-18. Mainboard Removal

10. Remove the mainboard from the top assembly ([Figure 1-19](#)).




Figure 1-19. Mainboard Removal




Figure 1-20. Mainboard

+ **IMPORTANT:**

Circuit boards >10 cm² have been highlighted with a yellow rectangle as shown in [Figure 1-20](#). Remove the circuit board and follow local regulations for disposal.

USB Board Removal

Prerequisite:

LCD Module Removal

1. Find the USB board (C) on the top assembly. Refer to [Figure 1-8](#).
2. Disconnect the 30-pin USB board FPC (B) from the mainboard connector (D) and the USB board connector (A) and remove the 30-pin USB board FPC ([Figure 1-21](#)).
3. Disconnect the 40-pin USB board FPC (F) from the mainboard connector (G) and the USB board connector (E) and remove the 40-pin USB board FPC ([Figure 1-21](#)).
4. Remove one (1) screw (H) securing the USB board in place ([Figure 1-21](#)).




Figure 1-21. USB Board Removal

5. Remove the USB board from the top assembly ([Figure 1-22](#)).



Figure 1-22. USB Board Removal

⚠ CAUTION:

USB board FPC (Flexible Printed Circuit) can be damaged if removed while the mainboard connector and USB board connector are locked.

LCD Panel Removal

Prerequisite:

[LCD Module Removal](#)

1. Carefully pull out the eDP cable from the LCD hinge compartment (A) ([Figure 1-23](#)).




Figure 1-23. LCD Panel Removal

2. Using a flat headed tool, pry open from the gap in one of the corners then slide the tool through the top side of the LCD module to release the LCD panel from the latches ([Figure 1-24](#)).



Figure 1-24. LCD Panel Removal

3. Continue along the left side of the LCD module ([Figure 1-25](#)).



Figure 1-25. LCD Panel Removal

4. Continue along the right side of the LCD module ([Figure 1-26](#)).



Figure 1-26. LCD Panel Removal

5. Lift and remove the LCD panel from the LCD cover ([Figure 1-27](#)).



Figure 1-27. LCD Panel Removal

Top Assembly Removal (Keyboard Removal)

Prerequisite:

Ensure that the **LCD module**, **Speaker module**, **Mainboard**, and **USB board** have been disassembled prior removing the top assembly.

⇒ NOTE:

The keyboard is included as part of the top assembly and can not be disassembled. In the event that the keyboard can no longer be used, replace the entire top assembly.



Figure 1-28. Top Assembly

Troubleshooting

This chapter shows you how to deal with common system problems. Read it before calling a technician if a problem occurs. Solutions to more serious problems require opening up the computer. Do not attempt to open the computer yourself; contact your dealer or authorized service center for assistance.

Recover your Chromebook

When your Chromebook's operating system (OS) isn't working properly, you can recover it. Recovery is removing and reinstalling the OS.

⇒ NOTE:

If you're using your Chromebook at work or school, ask [your administrator](#) for help.

Administrators: For more help, contact Google support.

When to recover

You might want to recover if:

- You see this error message: "Chrome OS is missing or damaged".
- You've tried [other troubleshooting steps](#) and nothing has fixed your issue.
- You've asked the experts in our [help forum](#) for help fixing your issue, and they recommend recovery.

What you need to get started

- The Chromebook with the "Chrome OS is missing or damaged" error.
- Another Chromebook, or a Windows or Mac computer with Chrome installed.
- A USB flash drive that can hold at least 8 GB, and that you don't mind erasing. If your Chromebook has an SD card slot, you can use an SD card instead.

+ IMPORTANT:

Recovery permanently erases everything on your Chromebook's hard drive, including your downloaded files. If possible, [back up your files](#) before you recover your Chromebook.

What you need to do

Step 1: Try less invasive steps



If you can sign in to your Chromebook, try these steps first:

1. Turn your Chromebook off, then back on again.
2. If your Chromebook still has an error, [reset to factory settings](#).

If neither of those steps fix the error, continue to Step 2.



Step 2: Download a new copy of the OS

On the working computer (not the Chromebook with the error):

1. If you're using a Mac or Windows computer:
 - a. If you haven't yet, [install Chrome](#).
 - b. Open **Chrome** .
 - c. Install the [recovery extension](#).
2. To open the recovery extension:
 - a. At the top right of your browser window, click **Extensions** .
 - b. To launch the extension popup, click on the "**Chromebook Recovery Utility**" extension. If the extension popup doesn't automatically appear on your screen, [make sure it's turned on](#).
3. Click **Get started**.
4. Click **Select** a model from a list, or type in the model number of the Chromebook you want to recover. To find this number, look at the bottom of the error message on your Chromebook screen.
5. Click **Continue**.
6. Insert your USB flash drive or SD card into the computer.
7. In the dropdown menu, choose the USB flash drive or SD card you inserted.
8. Click **Continue**.
9. Click **Create now**.
10. When you see a message saying that your recovery media is ready, remove the USB flash drive or SD card from the computer.




Step 3: Enter recovery mode

On the Chromebook with the error:

1. If you have anything connected to this Chromebook (such as a mouse or external hard drive), remove it.
2. Enter recovery mode:
 - Chromebook: Press and hold **Esc + Refresh** , then press **Power** . Let go of **Power**. When a message shows on the screen, let go of the other keys.
 - Chromebox: First, turn it off. Using a paper clip or similar object, press and hold the [recovery button](#). Press the **Power** button to turn the Chromebox back on. When you see a message on screen, release the recovery button.
 - Chromebit: First, unplug it from power. Using a paper clip or similar object, press and hold the [recovery button](#). Plug the Chromebit back in to power. When you see a message on screen, release the recovery button.

- Chromebook tablet: Press and hold the **Volume Up**, **Volume Down**, and **Power** buttons for at least 10 seconds, then release them.
3. You'll see one of these messages:
 - "Chrome OS is missing or damaged. Please insert a recovery USB stick or SD card."
 - "Please insert a recovery USB stick or SD card."
 4. Insert the USB flash drive or SD card that you used to create recovery media.
 5. Follow the on-screen instructions.




Make sure the recovery extension is turned on

1. On your computer, open **Chrome** .
2. At the top right, click **Extensions**  > **Manage extensions**.
3. Next to "Chromebook Recovery," toggle the switch to the right.
4. Optional: You can also click **Details** and toggle the switch to the right.
5. Once the extension is on, in the extension panel in your browser, click on the extension to open the popup.
6. Optional: If you use the extension frequently, you can pin it .

Optional: Reuse your USB flash drive or SD card

After recovering your Chromebook, you'll need to erase the recovery media if you want to reuse your USB flash drive or SD card to store other files.

To erase the recovery media:

1. On your computer, open **Chrome** .
2. At the top right, click **Extensions** .
3. To launch the extension popup, click on the "**Chromebook Recovery Utility**" extension.
4. In the extension popup, click **Settings** .
5. Click **Erase recovery media**.
6. From the dropdown menu, select the USB drive or SD card you'd like to erase.
7. Click **Continue**.
8. Make sure the storage device you used for recovery is listed.
9. Click **Erase now**.
10. The tool will erase everything on your USB drive or SD card. When you see the message "Your recovery media has been erased," click **Done**.
11. Remove the USB flash drive or SD card from the computer.
12. Format the storage device using a tool provided by your operating system.

Fix problems with recovery

"An unexpected error has occurred".

1. [Erase the storage device](#), then [try recovery again](#).
2. Try using a different USB flash drive or SD card to recover. Some USB flash drives and SD cards don't work well with recovery.

If you're still having problems, contact your Chromebook manufacturer for help. [Learn how to contact your manufacturer](#).

"Please remove all connected devices and start recovery".

First, remove anything that's connected to your Chromebook, such as a mouse, SD card or external hard drive. Then follow the steps to [enter recovery mode](#).

"The device you inserted does not contain Chrome OS".

First, make sure that you inserted the USB drive or SD card that you used to create recovery media.

If you're using the correct storage device, but still see this error, the storage device might not be working properly.

1. [Erase the storage device](#), then [try recovery again](#).
2. Try using a different USB flash drive or SD card to recover. Some USB flash drives and SD cards don't work well with recovery.

If you're still having problems, contact your Chromebook manufacturer for help. [Learn how to contact your manufacturer](#).

"The security module on this device is not working".

First, ask our experts for help:

- "If you use your Chromebook at work or school, contact your administrator. Administrators: contact Google support.
- "Chat with experts on the [Chromebook help forum](#).

If you're still having problems, contact your manufacturer to repair your Chromebook. [Learn how to contact your manufacturer](#).

FRU (Field Replaceable Unit) List

Please contact your local service center to find out how to obtain the part or replace your device.

Exploded Diagrams




Figure 1-29. System Exploded Diagram

Table 1-1. System Exploded Diagram

No.	Description	No.	Description
1	Base Cover	6	2nd Camera Cable
2	WLAN Module	7	Battery Pack
3	USB Board	8	Top Assembly
4	30-pin USB Board FPC	9	LCD Module
5	40-pin USB Board FPC	10	Mainboard





Figure 1-30. LCD Assembly Exploded Diagram

Table 1-2. LCD Assembly Exploded Diagram

No.	Description	No.	Description
1	LCD Panel + LCD Bezel	7	G-Sensor Board
2	eDP Cable	8	Microphone Board
3	Screw x 2	9	Camera Module
4	Screw x 6	10	G-Sensor Cable
5	LCD Hinge L	11	LCD Hinge R
6	LCD Cover	12	WLAN Antenna (MAIN and AUX)

Check for updates yourself

1. Turn on your Chromebook.
2. Connect your Chromebook to Wi-Fi.
3. At the bottom right, select the time.
4. Select **Settings** .
5. At the bottom of the left panel, select **About Chrome OS**.
6. Under "Google Chrome OS", you'll find which version of the Chrome operating system your Chromebook uses.
7. Select **Check for updates**.
8. If your Chromebook finds a software update, it will start to download automatically.

Factory reset your Chromebook

1. Sign out of your Chromebook.
2. Press and hold **Ctrl + Alt + Shift + r**.
3. Select **Restart**.
4. In the box that appears, select **Powerwash > Continue**.
5. Follow the steps that appear and sign in with your Google Account.

⇒ **NOTE:**

The account you sign in with after you reset your Chromebook will be the owner account.