

In [EFI Shell]

- 1.1 Get Acer BIOS Package.
- 1.2 Copy "EFI" and "ROM" folders including files to a EFI Shell bootable drive.
- 1.3 Power on System and press during POST LOGO to entry BIOS setup.
- 1.4 Set [Authentication]->[Secure Boot]->Disable.
- 1.5 Press <F10> or select [Exit]->[Save & Exit Setup] to save changes.
- 1.6 Boot to EFI Shell.
- 1.7 Key in 'cd EFI' (Go to Shell path, e.g. "fs0:\EFI")
- 1.8 Key in 'flashx.nsh' or 'flashx' for no ME data to update.
And following pictures are reference only.

```
Shell> fs0:
fs0:\> cd EFI
fs0:\EFI> flashx
```

- 1.9 Press <Enter> and start to flash System BIOS.

```
Shell> fs0:
fs0:\> cd EFI
fs0:\EFI> flashx
flashx> AfuEfix64.efi ..\ROM\P11-A0.CAP /P /B /N /R /X
-----+
|              AMI Firmware Update Utility v3.03.00              |
|      Copyright (C) 2012 American Megatrends Inc. All Rights Reserved.      |
+-----+
Reading FLASH ..... done
Secure Flash enabled, recalculate ROM size with signature...
- FFS checksums ..... ok
Loading capsule to secure memory buffer ...done
Erasing Boot Block.... done
Updating Boot Block... done
Verifying Boot Block... done
Erasing Main Block.... done
Updating Main Block... done
Verifying Main Block.. done
Erasing NVRAM Block... done
Updating NVRAM Block.. done
Verifying NVRAM Block.. done

fs0:\EFI>
```

- 1.10 Reboot system and Press to enter BIOS setup menu.
- 1.11 Select [Load default setting], then [Save & Exit Setup].