

AMIUCP Flash BIOS SOP


Document Revision: v1.0

Issue Date: 2018/09/07


Author: Helena Zeng

AMIUCP FLASH BIOS


1. Copy UCP package to HDD
2. In UCP folder , only one *.exe file ,select it and run as administrator




3. BIOS update progress as below, will show shut down prompt, please input "Y", system will shutdown and reboot automatically.




After rebooting, system will enter flashing interface and update BIOS automatically.




4. System will reboot automatically after finishing updating. When system rebooting, please press **[Del]** key to enter Setup Utility to check BIOS version.



5. Please press **[F9]** key to Load Optimized Default setting.



6. Press **[F10]** to save configuration and reset and select "Yes" and Press **[Enter]** key.



7. Flash BIOS is finished.