

AMI UEFI BIOS Flash SOP for Windows


Document Revision: v1.0

Issue Date: 2018/07/16


Author: Helena Zeng

Flash UEFI BIOS SOP for Windows


1. Copy BIOS folder to HDD
2. In BIOS folder , select WIN folder and run “FLASH.bat” or “FLASH_M” as administrator




3. If Bios update fail, will show this error message.




4. BIOS update progress as below, will show shut down prompt, please input “Y”, system will shutdown and reboot automatically.




After rebooting, system will enter flashing interface and update BIOS automatically.




5. System will reboot automatically after finishing updating. When system rebooting, please press **[Del]** key to enter Setup Utility to check BIOS version.



6. Please press **[F9]** key to Load Optimized Default setting.



7. Press **[F10]** to save configuration and reset and select "Yes" and Press **[Enter]** key.



8. Flash BIOS is finished.