


# UCP Flash Utility SOP


v1.1

## 1. Use File Explorer into UCP folder




## 2. Execute the \*.exe file

## 3. If you see the UAC prompt message, press Yes




## 4. Wait for completion and press "Y" to restart the system



## 5. System Auto Power on into BIOS “Flashing...”

## 6. Start flash update automatically



7. When the flashing is completed, the system will automatically restart.  
Please press “Delete” to enter BIOS Setup Menu.
8. Select “Load Default Setting” and press “Enter”. Select “Yes” to load default settings.



9. Select “Save & Exit Setup” and press “Enter”.

**10. Select “Yes” to restart.**

