






Flashing EC FW SOP

Step 1: Enter folder and click **IFU_XE64_v1091**

	Hulk_V60.bin	2016/11/16 上午 ...	IZArc Archive	64 KB
	IFU_XE64_v1091.exe	2016/11/15 下午 ...	應用程式	8,943 KB
	uiset.ini	2016/11/15 下午 ...	組態設定	1 KB

Step 2 : It will show flashing interface and click **load*.bin** to choose **Hulk_V60.bin** then click **“Open”**



Step 3:

Click “**Flash**” and tool will show up warning message

Choose “**Cancel**” , Warning message will disappear to inform user save excel/Power point/word ..any document before flashing

Step 4:


If all document done to save, please do below procedure

- a. follow Step1/Step2 to load bin file
- b. Click “**Flash**” icon
- c. Click “**OK**” to flash EC FW



Step 5:

After flashing , System will shut-down and boot up automatically



Step 6 :

When system boot up again , press “**Delete**” of keyboard to enter Bios set up menu , EC FW will show 6.0 means flash FW is done .

