


EFI Update EC FW SOP

Release Date: 2018/06/05

IN [EFI SHELL]

1. Copy "EFI" and "ROM" folder including files to a EFI Shell bootable drive.
2. Power on System and press during POST LOGO to entry BIOS setup.
3. Set [Authentication]-> [Secure Boot]->Disable.
4. Power on System and Boot to EFI Shell
5. Enter 'Flash.nsh' and following pictures are reference only, and <Enter> to start flash EC FW

```
\Copperbox_V1.00_20180601\EFI>FLASH.nsh
```




```
ITE Flash Utility Version : 2.2.7

Device ID       : EF 30 11 0
SPI Vendor      : Winbond
Block Number    : 0

Eraseing...     : [Progress Bar] -- Erase OK.
Erase Verify... : [Progress Bar] -- Verify OK.
Programing...   : [Progress Bar] -- Programing OK.
Verify...       : [Progress Bar] -- Verify OK.
FS0:\Copperbox_V1.00_20180601\EFI\> _
```

6. Shutdown system and remove AC power cord.
7. Plug AC power cord Reboot system and enter BIOS interface to check EC FW version is correct.



```
BIOS Setup Utility
Main Advanced Power Authentication Security Boot

System BIOS
Version R01-A0
Build Date 05/16/2018
EC Firmware
Version 1.00
Build Date 06/01/2018
Processor
```