



Windows Update EC FW SOP

Release Date: 2018/06/05

1. Open Flash EC FW tool (IFU_XE64_v1050).



2. EC tool will flash FW automatically.
3. progress bar run to 100%, showing Checksum OK.



4. Shutdown system and remove AC power cord.
5. Plug AC power cord Reboot system and enter BIOS interface to check EC FW version is correct.

