

# EFI Flash SOP


v1.4

1. When you see the LOGO or hear one short beep, please press “Delete” to enter BIOS Setup Utility.


2. Choose “Authentication” page and select “Secure Boot” to disabled.



3. BIOS Setup Utility will disable “Secure Boot”




**4. Choose “Boot Options” page and select “Boot Menu” to Enabled.**



**5. Choose “Exit” page and select “Save & Exit Setup” and press “Enter”.**

6. Select “Yes” to restart.



7. Press hot key F12 to enter Boot Menu, and select EFI USB thumbdrive.
8. Under the EFI system, and choose the Removable BlockDevice group  
( the Removable BlockDevice location is dynamic.)  
E.g. In this figure, users should key in fs5: in Shell command line.

```

fs2 :HardDisk - Alias hd2ze blk2
  Acpi(PNP0A03,0)/Pci(1F12)/?/HD(Part4,Sig346BC586-3025-4D0E-9603-68E5D2C25B38)
fs3 :HardDisk - Alias hd2ff blk3
  Acpi(PNP0A03,0)/Pci(1F12)/?/HD(Part5,Sig786109A0-E698-4366-AACD-9D58FCCE46D)
fs4 :HardDisk - Alias hd22g blk4
  Acpi(PNP0A03,0)/Pci(1F12)/?/HD(Part6,SigF1FABDB5-D18E-4D54-87BF-525E95B0608D)
fs5 :Removable HardDisk - Alias hd15b0d0b blk5
  Acpi(PNP0A03,0)/Pci(1F12)/?/HD(Part1,Sig0189F303)
blk0 :HardDisk - Alias hd22b fs0
  Acpi(PNP0A03,0)/Pci(1F12)/?/HD(Part1,Sig31FD0B73-A723-450C-B5AC-38CD1B95B4C2)
blk1 :HardDisk - Alias hd22c fs1
  Acpi(PNP0A03,0)/Pci(1F12)/?/HD(Part2,Sig5C776472-D735-4BF7-9D2E-955AD8103B62)
blk2 :HardDisk - Alias hd22e fs2
  Acpi(PNP0A03,0)/Pci(1F12)/?/HD(Part4,Sig346BC586-3025-4D0E-9603-68E5D2C25B38)
blk3 :HardDisk - Alias hd22f fs3
  Acpi(PNP0A03,0)/Pci(1F12)/?/HD(Part5,Sig786109A0-E698-4366-AACD-9D58FCCE46D)
blk4 :HardDisk - Alias hd22g fs4
  Acpi(PNP0A03,0)/Pci(1F12)/?/HD(Part6,SigF1FABDB5-D18E-4D54-87BF-525E95B0608D)
blk5 :Removable HardDisk - Alias hd15b0d0b fs5
  Acpi(PNP0A03,0)/Pci(1D10)/Usb(1, 0)/Usb(3, 0)/HD(Part1,Sig0189F303)
blk6 :HardDisk - Alias (null)
  Acpi(PNP0A03,0)/Pci(1F12)/?/HD(Part3,SigC2D33479-D097-4DDF-91F5-00CAB15B5E5C)
blk7 :BlockDevice - Alias (null)
  Acpi(PNP0A03,0)/Pci(1F12)/?
blk8 :BlockDevice - Alias (null)
  Acpi(PNP0A03,0)/Pci(1F12)/?
blk9 :Removable BlockDevice - Alias (null)
  Acpi(PNP0A03,0)/Pci(1D10)/Usb(1, 0)/Usb(3, 0)

```

Press ESC in 4 seconds to skip **startup.nsh**, any other key to continue.  
 Shell> fs5:~

## 9. Enter “EFI” folder, and then enter “AFU” folder.

```

fs5:\P11-A0\EFI> dir
Directory of: fs5:\P11-A0\EFI

07/30/12 10:51a <DIR>          0 .
07/30/12 10:51a <DIR>          0 ..
07/29/12 04:19p <DIR>          0 AFU
      0 File(s)        0 bytes
      3 Dir(s)

fs5:\P11-A0\EFI>

```

## 10. Type flash.nsh, and use it to flash the ROMs.

```

fs5:\P11-A0\EFI\AFU> dir
Directory of: fs5:\P11-A0\EFI\AFU

07/30/12 10:51a <DIR>          0 .
07/30/12 10:51a <DIR>          0 ..
07/17/12 11:41a      r    334,448 AfuEfFix64.efi
07/30/12 11:49a           46 flash.nsh
      2 File(s)     334,494 bytes
      2 Dir(s)

fs5:\P11-A0\EFI\AFU> flash.nsh

```

## 11. After step 10, we will see the following actions.

```

fs5:\P11-A0\EFI\AFU> flash.nsh
flash_x64.nsh> AfuEfix64.efi ...\\Rom\P11-A0.CAP /P /B /N /R
+
|          AMI Firmware Update Utility v3.02.00           |
|          Copyright (C)2012 American Megatrends Inc. All Rights Reserved.   |
+-----+
Reading flash ..... done
Secure Flash enabled, recalculate ROM size with signature...
- FFS checksums ..... ok
Loading capsule to secure memory buffer ... done
Erasing Boot Block ..... done
Updating Boot Block ..... done
Verifying Boot Block ..... done
Erasing Main Block ..... done
Updating Main Block ..... done
Verifying Main Block ..... done
Erasing NVRAM Block ..... done
Updating NVRAM Block ..... done
Verifying NVRAM Block ..... done

fs5:\P11-A0\EFI\AFU> .

```

- 12.** Press the power button to shut down the system.
- 13.** Boot system. When you hear two short beeps, please press “Delete” to enter BIOS Setup Menu.
- 14.** Select “Load Default Setting” and press “Enter”. Select “Yes” to load default settings.



- 15.** Select “Save & Exit Setup” and press “Enter”.

**16. Select “Yes” to restart.**

