Actiontec Firmware Upgrade Procedure

Hardware Requirements:

1. Actiontec Device
2. Actiontec power adapter
3. USB thumb drive
4. HDMI Cable
5. TV with HDMI input

How to upgrade Actiontec adapter Firmware:

Note: The following assumes you have downloaded the Actiontec Firmware.zip file.

1. Open Windows Explorer.
2. Unzip the Actiontec Firmware zip file to a location on your PC or USB thumb drive.
3. Open the Firmware folder and Copy the "**install.img**" file to the **"root"** of your USB thumb drive.
   Note: The image file must be in the **root** of the thumb drive.
4. Plug the USB thumb drive into the Actiontec adapters USB port.



5. Plug the HDMI cable into the Actiontec adapter.



6. Plug the other end the HDMI cable into the TV.
7. Use a paper clip to push in and hold the **Reset** button and then plug-in the Power adapter.



8. On the TV screen. You should see "Please wait for USB update" within a few seconds.



9. Now release the reset button.

Actiontec Firmware Upgrade Procedure

10. This will start installing the new firmware as shown in TV screen image below.



11. The adapter will automatically reboot after completing the installation.
12. Remove the USB thumb drive.
13. Now that the adapter has rebooted, it is ready for a WiDi enabled PC to connect as shown in the image below.

