


Launch .bat with administrator

- Use correct package for FW reflash on x64 and x86 system.
- Run Upgrade.bat with “Run as administrator”



- FW will reflash to PR#2199026 as below. The tool will auto check if current platform needs to update.

