


Windows Flash S.O.P

Precondition


1. Windows Flash utility
2. Rom file

Procedure

1. Copy the Windows flash utility package and Rom file to the device's desktop, which contains the Windows flash utility and the BIOS binary file



2. Execute the FB_WIN.bat to start flash BIOS. After flash initialization, Windows system will restart to flash BIOS.



Please do not remove the AC power!

Insyde H20FFT (Flash Firmware Tool) Version 1.00.36.00
Copyright (c) 2013, Insyde Software Corp. All Rights Reserved.

Loading New BIOS Image File: Done

Current BIOS Model Name: BayTrail
New BIOS Model Name: BayTrail
Current System BIOS Version: 000_normal2
New BIOS Image Version: 000_normal

75%