


In [Windows Mode]

- 1.1 Get Acer BIOS Package.
- 1.2 Copy "WIN" and "ROM" folders including files to a storage device.
- 1.3 Power on System and press during POST LOGO to entry BIOS setup.
- 1.4 Set [Authentication]->[Secure Boot]->Disable.
- 1.5 Press <F10> or select [Exit]->[Save & Exit Setup] to save changes.
- 1.6 Boot to Windows.

[By Windows command line](#)


2. Run Command Prompt as **Administrator** in Windows.
<Windows 10>



Windows

2.1 Key in 'cd win' (Go to BIOS path, e.g.

"E:\Predator_X299R4-AA_R01-A0_(20171103)_BIOS\Normal\WIN")



```
Administrator command prompt Flash x64.bat

Microsoft Windows [Version 10.0.15063]
(C) 2017 Microsoft Corporation. All rights reserved.

C:\Users\user> e:


E:\> cd "Predator_X299R4-AA_R01-A0_(20171103)_BIOS"

E:\Predator_X299R4-AA_R01-A0_(20171103)_BIOS> cd Normal

E:\Predator_X299R4-AA_R01-A0_(20171103)_BIOS\Normal> cd WIN
```

2.2a. Key in 'flash.bat' or 'flash' for 32-bit Windows and following pictures are reference only.

b. Key in 'flash_x64.bat' or 'flash_x64' for 64-bit Windows and following pictures are reference only .



```
Administrator command prompt Flash x64.bat

Microsoft Windows [Version 10.0.15063]
(C) 2017 Microsoft Corporation. All rights reserved.


C:\Users\user> e:

E:\> cd "Predator_X299R4-AA_R01-A0_(20171103)_BIOS"

E:\Predator_X299R4-AA_R01-A0_(20171103)_BIOS> cd Normal

E:\Predator_X299R4-AA_R01-A0_(20171103)_BIOS\Normal> cd WIN

E:\Predator_X299R4-AA_R01-A0_(20171103)_BIOS\Normal\WIN> FLASH_x64.bat
```

2.3 Press <Enter> system will enter flash BIOS and auto reboot.

```
Administrator command prompt Flash x64.bat

Microsoft Windows [Version 10.0.15063]
(C) 2017 Microsoft Corporation. All rights reserved.

C:\Users\user> e:

E:\> cd "Predator_X299R4-AA_R01-A0_(20171103)_BIOS"

E:\Predator_X299R4-AA_R01-A0_(20171103)_BIOS> cd Normal

E:\Predator_X299R4-AA_R01-A0_(20171103)_BIOS\Normal> cd WIN

E:\Predator_X299R4-AA_R01-A0_(20171103)_BIOS\Normal\WIN> FLASH_x64.bat

E:\Predator_X299R4-AA_R01-A0_(20171103)_BIOS\Normal\WIN> AFUWINx64.exe ..\ROM\R01-A0.CAP /P /B /N /R /MEUL /CAPSULE /Q

+-----+
|               AMI Firmware Update Utility v5.09.02.1384               |
|      Copyright (C)2017 American Megatrends Inc. All Rights Reserved.      |
+-----+
```

2.4 Press to enter BIOS setup menu.