

AMD BIOS Update SOP for Windows V1.01

Release Date: 2019/01/21

In [Windows]

1. Media Preparing

- 1.1 Get Acer BIOS Package.
- 1.2 Copy "Service\WIN" and "Service\ROM" folders including files to a storage device.

2. BIOS Setting


- 2.1 Power on system and press during POST LOGO to entry BIOS setup Menu.
- 2.2 Set [Authentication]→[Secure Boot]→[Disabled].
- 2.3 Press <F10> or select [Exit]→[Save & Exit Setup] to save changes.

3. Flash BIOS

- 3.1 Boot to Windows system.
- 3.2 For your Windows version, run [Command Prompt] as administrator.
Follow the picture below.

[Windows 7]

[Start]→[All Programs]→[Accessories]→[Command Prompt]→
[Click on the right]→[Run as administrator]



AMD BIOS Update SOP for Windows V1.01


Release Date: 2019/01/21

[Windows 8.x]

[Start]→[Apps]→[Windows System]→[Command Prompt]→
[Click on the right]→[Run as administrator]



Please press [Yes], If you have displayed this message.



AMD BIOS Update SOP for Windows V1.01

Release Date: 2019/01/21

3.3 Change directory to Step 1.2 file path

(e.g. "cd C:\Users\RS1\Desktop\VLONGMEN_P3A4-AM2_D03_20190121_BIOS\Service\WIN").

3.4 According to your OS-bit version to select batch file key in "FLASH.bat" or "FLASH_X64.bat" correspond to x86 or x64-bit OS.

```
Microsoft Windows [Version 10.0.15063]
(C) 2017 Microsoft Corporation. All right reserved.

C:\Users\user>e:

E:\>cd WIN

E:\WIN>FLASH_x64.bat
```

3.5 Press <Enter> and start to flash system BIOS.

```
Microsoft Windows [Version 10.0.15063]
(C) 2017 Microsoft Corporation. All right reserved.

C:\Users\user>e:

E:\>cd WIN

E:\WIN>FLASH_x64.bat

E:\WIN>AFUWINx64.exe ..\ROM\D03.CAP /P /B /N /R /K /CAPSULE


+-----+
|              AMI Firmware Update Utility v5.09.02.1384              |
|      Copyright (C)2017 American Megatrends Inc. All Rights Reserved.      |
+-----+

Reading flash ..... done
- FFS checksums ..... ok
- Check RomLayout ..... Ok .

Loading capsule to secure memory buffer . . . done
System is going to shutdown, are you ready? (Y/N) . . . _
```

3.6 Press<Y>, system will be going to shutdown.

3.7 System will auto reboot and flash BIOS.



4. Reboot and Load Default

- 4.1 Please reboot the system.
- 4.2 Press to enter BIOS setup menu.
- 4.3 Press <F9> or select [Exit] → [Load Default Settings] to load optimized settings.
- 4.4 Press <F10> or select [Exit] → [Save & Exit Setup] to save changes.