

In [EFI Shell]

- 1.1 Get Acer BIOS Package
- 1.2 Copy "EFI" and "ROM" folders including files to a storage device.
- 1.3 Power on System and press during POST LOGO to entry BIOS setup .
- 1.4 Set [Authentication]->[Secure Boot]->Disable.
- 1.5 Set [Launch CSM]->Never.
- 1.6 Press <F10> or select [Exit]->[Save & Exit Setup] to save changes.
- 1.7 Power on System and Boot to EFI Shell
- 1.8 Key in 'cd EFI' (Go to Shell path like "fs0:\EFI")
- 1.9 Key in 'flash.nsh' or 'flash' and following pictures are reference only.

```
Shell> fs0:  
fs0:\> cd EFI  
fs0:\EFI> FLASH.nsh
```

- 1.10 Press <Enter> and start to flash System BIOS and ME firmware.

```
FLASH.nsh> AfuEfix64.efi ..\ROM\R01-A0.CAP /P /B /N /R /MEUL /CAPSULE
```

```
-----+-----  
|               AMI Firmware Update Utility v5.09.02.1384               |  
|               Copyright (C)2017 American Megatrends Inc. All Rights Reserved.               |  
+-----+-----
```

```
Reading flash ..... done  
- FFS checksums ..... ok  
- Check RomLayout ..... Ok .  
Loading capsule to secure memory buffer ... done  
Input the ME Local data into the BIOS ..... done  
System is going to shut down, are you ready? (Y/N) ... _
```

- 1.11 Press<Y>, system will be going to shut down.
- 1.12 System will auto reboot and flash BIOS.

