


COMMERCEL Windows Flash Utility


SOP

v1.7


1. The lower left corner of the screen, scan windows



2. Type CMD
3. Mouse pointer Command Prompt, then click mouse Right button
4. Click mouse left button run "Run as Administrator"



5. Use Type “CD” “Your package folder name” into WIN folder



6. Type flash.bat, and use it to flash the ROMs.

7. Wait Afuwin Tools load BIOS, key in “Y” then System Auto Power off



```



+-----+
|               AMI Firmware Update Utility v5.10.01.1670               |
|               Copyright (C)2018 American Megatrends Inc. All Rights Reserved. |
+-----+
Reading flash ..... done
- FFS checksums ..... ok
- Check RomLayout ..... Ok.
- Preserve BIOS Setup Config..... Enable.
Loading capsule to secure memory buffer ... done
Input the ME Local data into the BIOS ..... done
System is going to shut down, are you ready? (Y/N)...

```

8. System Auto Power on into BIOS “Recovery”

9. Start recovery automatically.





Wait it completed.

10. The system will auto reboot and then enter to OS.