

In [Windows Mode]

- 1.1 Get Acer BIOS Package.
- 1.2 Copy "WIN" and "ROM" folders including files to a storage device.
- 1.3 Power on System and press during POST LOGO to entry BIOS setup.
- 1.4 Set [Authentication]->[Secure Boot]->Disable.
- 1.5 Press <F10> or select [Exit]->[Save & Exit Setup] to save changes.
- 1.6 Boot to Windows.


[By Windows command line](#)

2. Run Command Prompt as **Administrator** in Windows.

< Windows 7>




< Windows 10 >



Windows

- 2.1 Key in "cd win" (Go to BIOS path , e.g. "E:\D02\WIN")
- 2.2 Key in "flash.bat" or "flash" and following pictures are reference only.
- 2.3 Press <Enter> and start to flash System BIOS



```
Administrator: Command Prompt
Microsoft Windows [Version 10.0.10240]
(c) 2015 Microsoft Corporation. All rights reserved.

C:\Windows\system32>E:

E:\>CD D02

E:\D02>CD WIN

E:\D02\WIN>FLASH

E:\D02\WIN>afuwinx64 ..\ROM\D02.rom /p /b /n /r
+-----+
|               AMI Firmware Update Utility  v5.08.00               |
|      Copyright (C)2015 American Megatrends Inc. All Rights Reserved.      |
+-----+
Reading flash ..... done
Secure Flash enabled, recalculate ROM size with signature... Enable.
- FFS checksums ..... ok
Loading capsule to secure memory buffer ... done
Erasing Boot Block ..... done
Updating Boot Block ..... done
Verifying Boot Block ..... done
Erasing Main Block ..... done
Updating Main Block ..... done
Verifying Main Block ..... done
Erasing NVRAM Block ..... done
Updating NVRAM Block ..... done
Verifying NVRAM Block ..... done

E:\D02\WIN>
```

- 2.4 Reboot system and Press to enter BIOS setup menu.
- 2.5 Select [Load default setting], then [Save & Exit Setup].