



Windows Flash Utility SOP

v1.7


1. The lower left corner of the screen, scan windows



2. Type CMD
3. Mouse pointer Command Prompt, Then Click mouse Right button
4. Click mouse left button run "Run as Administrator"



5. Use Type “CD” “Your package folder name” into WIN folder





```
Administrator: Command Prompt
Microsoft Windows [Version 10.0.15063]
(c) 2017 Microsoft Corporation. All rights reserved.

C:\Windows\system32>cd C:\Service\WIN
C:\Service\WIN>FLASH.bat
```

6. Type flash.bat, and use it to flash the ROMs.

7. Wait Afuwin Tools load BIOS,Then System Auto Power off





Wait it completed.



- 8. Press any key to reboot the system. (Recovery completed).**
- 9. Boot system. Please press "Delete" to enter BIOS Setup Menu.**
- 10. Select "Load Default Setting" and press "Enter". Select "Yes" to load default settings.**



11. Select “Save & Exit Setup” and press “Enter”.

12. Select “Yes” to restart.

