

In [EFI Shell]

- 1.1 Get Acer BIOS Package
- 1.2 Copy "EFI" and "ROM" folder including files to a EFI Shell bootable drive
- 1.3 Power on System and press during POST LOGO to entry BIOS setup .
- 1.4 Set [Authentication]->[Secure Boot]->Disable.
- 1.5 Set [Launch CSM]->Never.
- 1.6 Press <F10> or select [Exit]->[Save & Exit Setup] to save changes.
- 1.7 Power on System and Boot to EFI Shell
- 1.8 Key in 'cd EFI'
- 1.9 Enter 'Flash.nsh' and following pictures are reference only.

```
Shell> fs0:  
fs0:\> cd EFI  
fs0:\EFI> Flash.nsh
```

- 1.10 Press <Enter> and start to flash EC FW.

```
ITE Flash Utility Version : 2.1.4  
  
Device ID       : EF 30 11 0  
SPI Vendor      : Winbond  
Block Number    : 1  
  
Erasing...     : ██████████ -- Erase OK.  
Erase Verify... : ██████████ -- Verify OK.  
Programing...  : ██████████ -- Programing OK.  
Verify...      : ██████████ -- Verify OK.
```

- 1.11 Shutdown system and remove AC power cord
- 1.12 Plug in power cord, power on system and Press to enter BIOS setup menu