



# AMI EFI BIOS supports a “recovery flash” mode to recovery BIOS from the boot block

v1.3


1. Put BIOS ROM (it may exist at \ROM\xxx.CAP) from BIOS folder to a USB storage.



2. After putting BIOS ROM to the USB storage, rename BIOS ROM file to RCVBOOT.CAP (i.e. P11-A0. CAP to RCVBOOT. CAP).
3. Plug USB storage to the system.
4. Press power button to boot the system.
5. The recovery function of BIOS will be executed. (you will hear a long beep and one short beep).
6. Press Proceed with flash update start recovery.



7. Wait it completed.



8. Flash update completed.



9. Press any key to reboot the system. (Recovery completed).