


DOS Flash Utility SOP

v1.2


1. Copy BIOS folder to USB storage.
2. Power on system.
3. When you see the LOGO or hear one short beep, please press “Delete” to enter BIOS Setup Utility.
4. Choose “Authentication” page and select “Secure Boot” to disabled.



5. BIOS Setup Utility will disable “Secure Boot”



6. Choose “Boot Options” page and select “Boot Menu” to Enabled.




7. Choose “Exit” page and select “Save & Exit Setup” and press “Enter”.

8. Select “Yes” to restart.



9. When you see the LOGO or hear one short beep, please press “Delete” to enter BIOS Setup Utility.

10. Choose “Boot Options” page and select “Launch CSM” to Always.



11. Choose “Exit” page and select “Save & Exit Setup” and press “Enter”.

12. Select “Yes” to restart.

13. Press hot key F12 to enter Boot Menu, and select USB thumbdrive.

14. Enter BIOS folder.

```
C:\>cd p11-a0
C:\P11-A0>_
```

15. Enter “DOS” folder.

```

.                <DIR>          07-30-12 10:51a
..               <DIR>          07-30-12 10:51a
DOS              <DIR>          07-29-12  4:19p
EFI              <DIR>          07-29-12  4:19p
ROM              <DIR>          07-29-12  4:20p
WIN              <DIR>          07-29-12  4:19p
0 file(s)        0 bytes
6 dir(s)         5,856.40 MB free

C:\P11-A0>_
```

16. Execute “BIOS_DOS.bat” file.

```
.          <DIR>          07-30-12  10:51a
..         <DIR>          07-30-12  10:51a
AFUDOS    EXE           161,008  07-04-12  4:54p
BIOS_DOS  BAT            58       07-30-12  10:51a
GPIOP     EXE           12,859  08-30-05  2:07p
MEONOFF   BAT             776    03-08-12  3:54p
Y         TXT              3       06-19-07  8:56p
          5 file(s)      174,704 bytes
          2 dir(s)      5,856.40 MB free

C:\P11-A0\DOS>
```

17. Process to flash BIOS (don't reset).


18. Press the power button to shut down the system.

19. Boot system and wait for finishing update BIOS.

20. When you see the LOGO or hear one short beep, please press “Delete” to enter BIOS Setup Menu.

21. Select “Load Default Settings” and press “Enter”.

22. Select “Yes” to load default setting.



23. Select “Save & Exit Setup” and press “Enter”.

24. Select “Yes” to restart.

