

BIOS Flash SOP

for


Acer Desktop

Document Type:	BIOS Flash SOP (AFUWIN)
Document Version:	V 3.0
Release Date:	4/25/2013
Author:	Johnny Wang

BIOS Flash SOP for Acer Desktop

For AMI Win Flash

1. Copy **BIOS Package** folder to USB Drive(**Note 1**)
2. Booting to Windows System.
3. Insert the USB Drive to System.
4. Please run command Prompt (Admin)




5. Enter to **BIOS Package \Service\Win** folder, typing **Flash** to execute.

```
Administrator: Command Prompt
C:\D11\Service\Win>flash
C:\D11\Service\Win>afuwinx64 ..\ROM\D11.CAP /p /b /n /r
+-----+
|          AMI Firmware Update Utility  v3.04.01          |
| Copyright (C)2012 American Megatrends Inc. All Rights Reserved. |
+-----+
Reading flash ..... done
- ME Data Size checking . ok
Secure Flash enabled, recalculate ROM size with signature...
- FFS checksums ..... ok
Loading capsule to secure memory buffer ... done
Erasing Boot Block ..... done
Updating Boot Block ..... done
Verifying Boot Block ..... done
Erasing Main Block ..... done
Updating Main Block ..... done
Verifying Main Block ..... done
Erasing NURAM Block ..... done
Updating NURAM Block ..... done
Verifying NURAM Block ..... done
C:\D11\Service\Win>
```

BIOS Flash SOP for Acer Desktop

6. Please press **Yes** Button if pup up UAC Message(User Account Control)



7. When WinFlash processing, The Mouse cursor and Keyboard will be locked.
8. The Processing finish done, Please manual restart the System.
9. When system reboot, display as below screen, please Press Del Enter BIOS.



10. Please Press F9 key to Load default Setting, and Press F10 Key to Exit.

Note 1: The package name is different base on release Package