

In [EFI Shell]

- 1.1 Get Acer BIOS Package
- 1.2 Power on System and press during POST LOGO to entry BIOS setup .
- 1.3 Set [Authentication]->[Secure Boot]->Disable.
- 1.4 Set [Launch CSM]->Never.
- 1.5 Press <F10> or select [Exit]->[Save & Exit Setup] to save changes.
- 1.6 Power on System and Boot to EFI Shell
- 1.7 Key in 'cd Predator_X29R4-AA_R01-A0_(20171103)_BIOS\Normal\EFI' (Go to Shell path like "fs0:\EFI")
- 1.8 Key in 'flash.nsh' or 'flash' and following pictures are reference only.

```
Shell> fs0:
fs0:\> cd Predator_X29R4-AA_R01-A0_(20171103)_BIOS\Normal\EFI
fs0:\ Predator_X29R4-AA_R01-A0_(20171103)_BIOS\Normal\EFI> FLASH.nsh
```


- 1.9 Press <Enter> and start to flash System BIOS and ME firmware.

```
FLASH.nsh> AfuEfix64.efi ..\ROM\R01-A0.CAP /P /B /N /R /MEUL /CAPSULE
```

```
+-----+
|               AMI Firmware Update Utility v5.09.02.1384               |
|               Copyright (C)2017 American Megatrends Inc. All Rights Reserved.               |
+-----+

Reading flash ..... done
- FFS checksums ..... ok
- Check RomLayout ..... Ok .
Loading capsule to secure memory buffer ... done
Input the ME Local data into the BIOS ..... done
System is going to shut down, are you ready? (Y/N) ... _
```

- 1.10 Press<Y>, system will be going to shutdown.
- 1.11 System will auto reboot and flash BIOS.



1.12 Clear CMOS and reboot system by the following steps.

- a. System Shutdown
- b. Remove AC Power
- c. Clear CMOS
- d. Reconnect AC Power
- e. Boot

1.13 Press to enter BIOS setup menu.