



# ECFW Update SOP for DOS


Release Date: 2016/01/14

## Step:


1. Make a MS-DOS bootable USB-disk.
2. Unzip the file of Acer released package to bootable USB-disk.
3. Plug the U-disk to system.
4. Power on system, press [DEL] key enters the BIOS menu.
5. Select the "Authentication" item, and then change the "Secure Boot" item to Disabled.




6. Select the "Boot Options" item, change the "Launch CSM" item to Always, change the "Boot Filter" item to Legacy.




7. Press [F10] key to Save & Exit Setup.
8. Press [F12] key while **system** reboot.
9. Select USB-disk boot to DOS.



10. Enter Flash.bat while boot MS-DOS.



11. Press [power-button] to shutdown system.
12. Unplug AC power cord, and then press power-button.
13. Plug power cord and press power button to power on.
14. Press [Del] key after system power on, and Check EC F/W version **that same with released.**



15. Resume your BIOS setting and power off.
16. Finish.

Remark: Please skip step 5~6 if your system BIOS setting is same as SOP setting.