




1. Unzip acer.zip.
2. Click acer folder and choose intel or amd platform.
3. Including your OS, click 32 or 64 folder.
4. Click mouse right key for RTNicPgW32 or RTNicPgW64 and click **Run as administrator**.




5. Click **yes** to allow this app.



6. Start FW update, don't close this window.




7. After proceeding 100%, please wait to start client tool.



8. When client tool FW display right FW version, FW update complete, please restart OS.

For intel version: 1.3.10.162462329

For amd version: 1.3.11.162462330



PS: IF your OS doesn't install Dash client tool , the FW update complete after proceeding 100% and display update complete(step7), please restart OS.