




LCD MONITOR

CZ320Q



User Guide
Quick Guide

Acer LCD Monitor Quick Start Guide (QSG)


Important safety instructions

Please read the following instructions carefully.


- To clean the LCD monitor screen:
 - Turn off the LCD monitor and unplug the power cord.
 - Spray a non-solvent cleaning solution onto a rag and clean the screen gently.
- Do not place the LCD monitor near a window. Exposing the monitor to rain, moisture or sunlight can severely damage it.
- Do not apply pressure to the LCD screen. Excessive pressure may cause permanent damage to the display.
- Do not remove the cover or attempt to service this unit yourself. An authorized technician should perform servicing of any nature.
- Store the LCD monitor in a room with a temperature of -20° to 60° C (-4° to 140° F). Storing the LCD monitor outside this range may result in permanent damage.
- Immediately unplug your monitor and call an authorized technician if any of the following circumstances occur:
 - Monitor-to-PC signal cable is frayed or damaged.
 - Liquid spills onto the LCD monitor or the monitor is exposed to rain.
 - The LCD monitor or case is damaged.
- In order to prevent damage to the LCD panel, do not place the monitor face down on a surface.

Connecting your monitor to a computer

- Turn off your computer and unplug your computer's power cord.
- Connect the signal cable to the VGA (optional) and /or HDMI (optional) and /or DP (optional) and /or MHL (optional) input socket of the monitor, and the VGA (optional) and /or HDMI (optional) and /or DP (optional) and /or MHL (optional) output socket of the graphics card on the computer. Then tighten the thumbscrews on the signal cable connector.
- Optional: Connect the audio input socket (AUDIO IN) of the LCD monitor and the line-out port on the computer with the audio cable.
- Insert the monitor power cable into the power port at the back of the monitor.
- Connect the power adapter and power cord to the monitor, then to a properly grounded AC outlet.



Note: Audio output is only for audio output model. Please check user manual for more instruction.



External controls

| | | |
|---|---|---|
| 1 | Power button | Turns the monitor on/off. Blue indicates power on. Amber indicates standby/ power saving mode. |
| 2 | Function key  | <ol style="list-style-type: none"> Press to view Main page. Press again to enter hotkey1 function. When the Function Menu is active, press this key to view the basic information for your monitor and current input or reset the custom color settings to the factory defaults. |
| 3 | Function key  | <ol style="list-style-type: none"> Press to view Main page. Press again to enter hotkey2 function. When the Function Menu is active, press this button to select scenario mode or game mode . |
| 4 | Function key  | <ol style="list-style-type: none"> Press to view Main page. Press again to enter Input select function. When the Function Menu is active, this button will quit the OSD. |
| 5 | Function key  | <ol style="list-style-type: none"> Press to view Main page. Press again to enter next function in the Function Menu. The single toggle button on the backside of the Display bezel operates like a joystick. To move the cursor, simply toggle the button in four directions. Press the button to select desired option. Green indicates operable. Grey indicates inoperable. |

Adaptive-Sync:

It can allow a Adaptive-Sync supported graphics source to dynamically adjust display refresh rate based on typical content frame rates for power efficient, virtually stutter free and low-latency display update.

Regulations and safety notices

FCC notices

This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

CE declaration of conformity

Hereby, Acer Inc., declares that this LCD monitor is in compliance with the essential requirements and other relevant provisions of EMC Directive 2014/30/EU, Low Voltage Directive 2014/35/EU, and RoHS Directive 2011/65/EU and Directive 2009/125/EC with regard to establishing a framework for the setting of ecodesign requirements for energy-related product.

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with EMC regulations.

Notice: Peripheral devices

Only peripherals (input/output devices, terminals, printers, etc.) certified to comply with the Class B limits may be attached to this equipment. Operation with non-certified peripherals is likely to result in interference to radio and TV reception.

Caution

Changes or modifications not expressly approved by the manufacturer could void the user authority, which is granted by the Federal Communications Commission, to operate this product.

In order to prevent damage to the monitor, do not lift the monitor by its base.

Operation conditions

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Notice: Canadian users

CAN ICES-3(B)/NMB-3(B)

Restriction on Hazardous Substances statement (India)

This product complies with the "India E-waste Rule 2011" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for the exemptions set in Schedule 2 of the Rule.

Disposal of waste equipment by user in private household in the European Union



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

SPECIFICATION

| | | |
|---|---|--|
| LCD Panel | Driving system | TFT Color LCD |
| | Size | 31.5" W (80cm) |
| | Pixel pitch | 0.36375 mm(H) x 0.36375mm(V) |
| | Brightness | 300cd/m ² (Typical) |
| | Contrast | 100,000,000:1Max. (ACM) |
| | Viewable angle (Typical) | 178° (H) 178° (V) (CR ≥ 10) |
| | Response time | 4ms (GTG,Typical) |
| | Panel Type | VA |
| | Video | Digital Interface |
| | H-Frequency | HDMI: 30~85KHz, DP : 85~85KHz, VGA/MHL: 30~83KHz |
| | V-Frequency | HDMI: 48~75Hz, DP: 48~75Hz, VGA/MHL: 23~75Hz |
| Display Colors | 16.7M Colors | |
| Dot Clock | 180MHz | |
| Max. Resolution | HDMI/DP: 1920X1080@75Hz VGA/MHL: 1920X1080@60Hz | |
| Plug & Play | VESA DDCI/DDC2B | |
| Energy Efficiency Class | A+ | |
| *Annual Energy Consumption(Typical) | 43 (kWh) (for HDMI-input Model) | |
| Power consumption @200cd/m ² | ON Mode | 29W(typ.) |
| | Sleep Mode | 0.45W(typ.) |
| | Off | 0.35W(typ.) |
| Input Connector | D-Sub(only D-Sub Model) DP (Only DP Model) MHL (Only MHL Model) HDMI(Only HDMI model) | |
| Input Video Signal | DP signal(Only DP-Input Model) HDMI signal(Only HDMI-Input Model) | |
| Speakers(Typical) | 2W x 2 | |
| Audio | Audio-Input (Only Audio-Input Model) | |
| | Audio-Output (Only Audio-Output Model) | |
| Maximum Screen Size | Horizontal:698.4mm Vertical:392.85mm | |
| Power Source | 100-240V~, 50/60Hz | |
| Environmental Considerations | Operating Temp: 5° to 35°C Storage Temp: -20° to 60°C Operating Humidity: 10% to 85% | |
| Dimensions | 722 (W) x 477.9-607.9(H) x 274.2(D)mm | |
| Weight (N. W.) | 11.15kg Unit (net) | |
| Mechanism spec | Tilt: -5° to +25° Swivel: +/- 60° Height adjustment: 130mm Pivot: No Detachable foot stand: Yes | |

| | | | |
|--|-----------|---|--|
| External Controls: | Functions | Brightness Contrast Black Boost Blue Light ACM Super Sharpness Auto Config H. Position V. Position Focus Clock Gamma Color Temp sRGB mode 6-axis Hue 6-axis Saturate Volume | Over Drive Aim point Language OSD Timeout Transparency Refresh rate num Input Auto Source Wide Mode Hot Key Assignment DDC/CI HDMI Black level Quick Start Mode Game Mode |
| * All specifications are subject to change without notice. | | | |

Find manuals and other documents for your Acer product on the official Acer support website.

*Annual energy consumption is calculated using the typical power consumption 4 hours per day, 365 days per year.