

# Software Upgrade Procedure

To upgrade your projector's software version, please follow Step 1 to Step 6 to complete upgrade process via USB driver.

Step 1: Download "Software upgrade" file from Acer's official website and unzip it. Put "XXXX.bin" file to root address of your USB drive and plug it to your projector.

Step 2: Turn on projector and select source by "Media"




Step 3: Select "Setting" and choose Software Upgrade by "USB drive."



# Software Upgrade Procedure


Step 4: System will confirm the firmware file from USB drive automatically

\*Please don't unplug the USB drive or turn off power during firmware upgrade.



Step 5: System is upgrading and will automatically turn off when the upgrade was completed.

\*Please don't unplug the USB drive or turn off power.



\*If it shows below information, please restart the projector and check if power and USB driver is unstable.

