Windows Flash Utility SOP

v1.5

1. **The lower left corner of the screen, scan windows.**



2. **Type CMD.**
3. **Mouse pointer Command Prompt, then click mouse right button.**
4. **Click mouse left button run “Run as Administrator”.**



5. **Use type “cd” “your package folder name” into WIN folder.**



6. **Type flash.bat, and use it to flash the ROM.**



7. **Wait Afuwin tools load BIOS, then press “Y” key to power off the system. If you set password in BIOS setup, it takes about 10~20 seconds to confirm that the password is correct.**
8. **System will auto power on into BIOS “Recovery” and proceed with flash update.**


BIOS Setup Utility
Main Advanced Power Authentication Security Boot Options Exit Flashing...
WARNING! System firmware is being updated.
Keyboard is locked.
DO NOT TURN THE POWER OFF !!!
Once firmware update is completed
system will be automatically rebooted
Backup Partition 1
Read Partition 1
13%
Screen
elect Item
lick: Select
Opt.
F7: Load User-defined Defaults
F8: Save as User-defined
F9: Optimized Defaults
(When Access Level is
Administrator)
F10: Save & Exit
ESC/Right Click: Exit
Version 2.19.1268. Copyright (C) 2002-2017, Acer Inc.


BIOS Setup Utility
Main Advanced Power Authentication Security Boot Options Exit Flashing...
WARNING! System firmware is being updated.
Keyboard is locked.
DO NOT TURN THE POWER OFF !!!
Once firmware update is completed
system will be automatically rebooted
Backup Partition 1
Copy CC to H2 above BPDT
70%
Screen
elect Item
lick: Select
Opt.
F7: Load User-defined Defaults
F8: Save as User-defined
F9: Optimized Defaults
(When Access Level is
Administrator)
F10: Save & Exit
ESC/Right Click: Exit
Version 2.19.1268. Copyright (C) 2002-2017, Acer Inc.


BIOS Setup Utility
Main Advanced Power Authentication Security Boot Options Exit Flashing...
WARNING! System firmware is being updated.
Keyboard is locked.
DO NOT TURN THE POWER OFF !!!
Once firmware update is completed
system will be automatically rebooted
Program new data
Write new main block...
38%
Screen
elect Item
lick: Select
Opt.
F7: Load User-defined Defaults
F8: Save as User-defined
F9: Optimized Defaults
(When Access Level is
Administrator)
F10: Save & Exit
ESC/Right Click: Exit
Version 2.19.1268. Copyright (C) 2002-2017, Acer Inc.



9. **Wait it completed, system will reboot automatically. (Recovery completed).**
10. **Boot system. Please press “Delete” to enter BIOS Setup Menu.**
11. **Select “Load Default Setting” and press “Enter”. Select “Yes” to load default settings.**



12. **Select “Save & Exit Setup” and press “Enter”.**
13. **Select “Yes” to restart.**


BIOS Setup Utility
Main Advanced Power Authentication Security Boot Options Exit
Save & Exit Setup
Discard Changes and Exit Setup
Save Changes
Discard Changes
Load Default Settings
Save as User Default Settings
Load User Default Settings
Exit system setup after saving the changes.
Save & Exit Setup
Save & Exit Setup?
Yes No
→←: Select Screen
↑↓/Click: Select Item
Enter/Dbl Click: Select
+/-: Change Opt.
F7: Load User-defined Defaults
F8: Save as User-defined
F9: Optimized Defaults
(When Access Level is Administrator)
F10: Save & Exit
ESC/Right Click: Exit
Version 2.19.1268. Copyright (C) 2002-2017, Acer Inc.