H6815 TI FW One key Download SOP

- **Download Mode：**

This mode is applied for firmware download.

One method to enter this mode is that you should press and hold keypad **Power** and **ENTER** together, then plug in power cord **(At least for 3 seconds)**. Release the two keypads until the **Power /Lamp /Temp LED all shows RED color**.

Download Mode

- ## Firmware Download

Download Tools Required：

Software required：

1. PC system：Windows 10
2. New version one key download *.exe file

Hardware required：

1. PC or Notebook：With USB port
2. Standard USB-A download cable (P/N:5K.3NQ01.001)

Firmware Download Procedure：

1. Connect USB cable to PC and projector
2. Let projector be in **Download Mode**
3. Execute one key download *.exe file
4. Press “Download”

5. Program run Erase procedure

6. Program run Programming procedure

7. Flash Programming Successful