

## In [DOS Mode]

- 1.1 Get Acer BIOS Package
- 1.2 Copy "DOS" and "ROM" folders including files to a DOS bootable drive
- 1.3 Power on System and press <Del> key during POST LOGO to entry BIOS setup.
- 1.4 Select the [Authentication]->[Secure Boot ] item and change setting to 'Disabled'.
- 1.5 Select the [Boot Options] -> [Launch CSM] item and change setting to 'Always'.
- 1.6 Select the [Boot Options] -> [Boot Filter] item and change setting to 'Legacy'.
- 1.7 Press <F10> or select [Exit]->[Save & Exit Setup] to save changes.
- 1.8 Boot to DOS prompt.
- 1.9 Key in 'cd dos' (Go to BIOS path, e.g. "C:\D10\DOS")
- 1.10 Key in 'flash.bat' or 'flash' and following pictures are reference only.

```
C:\>cd d10
```

```
C:\D10>cd dos
```

```
C:\D10\DOS>flash_
```

- 1.11 Press <Enter> and start to flash System BIOS.

```
C:\D10\DOS>flash
```

```
C:\D10\DOS>afudos ..\ROM\D10.8M /p /b /n /r
```

```
+-----+
:               AMI Firmware Update Utility  v5.07
:      Copyright (C)2014 American Megatrends Inc. All
+-----+
```

```
Reading flash ..... done
Secure Flash enabled, recalculate ROM size with sign
- FFS checksums ..... ok
Loading capsule to secure memory buffer ... done
Erasing Boot Block ..... done
Updating Boot Block ..... done
Verifying Boot Block ..... done
Erasing Main Block ..... done
Updating Main Block ..... done
Verifying Main Block ..... done
Erasing NVRAM Block ..... done
Updating NVRAM Block ..... done
Verifying NVRAM Block ..... done
```

```
C:\D10\DOS>
```

- 1.12 Reboot system and Press <Del> to enter BIOS setup menu.
- 1.13 Select [Load default setting], then [Save & Exit Setup].