

In [EFI Shell]

- 1.1 Get Acer BIOS Package.
- 1.2 Copy "EFI" and "ROM" folders including files to a EFI Shell bootable drive.
- 1.3 Power on System and press during POST LOGO to entry BIOS setup.
- 1.4 Set [Authentication]->[Secure Boot]->Disable.
- 1.5 Set [Launch CSM]->Never
- 1.6 Press <F10> or select [Exit]->[Save & Exit Setup] to save changes.
- 1.7 Boot to EFI Shell.
- 1.8 Key in 'cd EFI' (Go to Shell path, e.g. "fs0:\EFI")
- 1.9 Key in 'flash.nsh' or 'flash' and following pictures are reference only.

```
Shell> fs0:  
  
fs0:\> cd EFI  
  
fs0:\EFI> flash_
```

- 1.10 Press <Enter> and start to flash System BIOS.

```
Shell> fs0:  
  
fs0:\> cd EFI  
  
fs0:\EFI> flash  
flash> AfuEfi64.efi ..\ROM\D10.8M /P /B /N /R  
+-----+  
|                               AMI Firmware Update Utility  v5.07.01  
|                               Copyright (C)2014 American Megatrends Inc. All Rights Reserved.  
+-----+  
Reading flash ..... done  
Secure Flash enabled, recalculate ROM size with signature... Enable.  
- FFS checksums ..... ok  
Loading capsule to secure memory buffer ... done  
Erasing Boot Block ..... done  
Updating Boot Block ..... done  
Verifying Boot Block ..... done  
Erasing Main Block ..... done  
Updating Main Block ..... done  
Verifying Main Block ..... done  
Erasing NVRAM Block ..... done  
Updating NVRAM Block ..... done  
Verifying NVRAM Block ..... done  
  
fs0:\EFI> _
```

- 1.11 Reboot system and Press to enter BIOS setup menu.
- 1.12 Select [Load default setting], then [Save & Exit Setup].