

## In [DOS Mode]

- 1.1 Get Acer BIOS Package
- 1.2 Copy "DOS" and "ROM" folders including files to a DOS bootable drive
- 1.3 Power on System and press <Del> key during POST LOGO to entry BIOS setup.
- 1.4 Select the [Authentication]->[Secure Boot ] item and change setting to 'Disabled'.
- 1.5 Select the [Boot Options] -> [Launch CSM] item and change setting to 'Always'.
- 1.6 Press <F10> or select [Exit]->[Save & Exit Setup] to save changes.
- 1.7 Boot to DOS prompt.
- 1.8 Key in 'cd dos' (Go to BIOS path, e.g. "C:\P11-A0\DOS")
- 1.9 Key in 'flash.bat' or 'flash' and following pictures are reference only.

```
C:\P11-A0\>cd dos  
C:\P11-A0\DOS>flash_
```

- 1.10 Press <Enter> and start to flash System BIOS.

```
C:\P11-A0\>cd dos  
C:\P11-A0\DOS>flash  
C:\P11-A0\DOS>afudos ..\ROM\P11-A0.CAP /p /b /n /r  
+-----+  
:                AMI Firmware Update Utility  v3.03.00                :  
:      Copyright (C)2012 American Megatrends Inc. All Rights Reserved.      :  
+-----+  
Reading flash ..... done  
Secure Flash enabled, recalculate ROM size with signature...  
- FFS checksums ..... ok  
Loading capsule to secure memory buffer ... done  
Erasing Boot Block ..... done  
Updating Boot Block ..... done  
Verifying Boot Block ..... done  
Erasing Main Block ..... done  
Updating Main Block ..... done  
Verifying Main Block ..... done  
Erasing NURAM Block ..... done  
Updating NURAM Block ..... done  
Verifying NURAM Block ..... done  
C:\P11-A0\DOS>_
```

- 1.11 Reboot system and Press <Del> to enter BIOS setup menu.
- 1.12 Select [Load default setting], then [Save & Exit Setup].