


In [Windows Mode]

- 1.1 Get Acer BIOS Package.
- 1.2 Copy "WIN" and "ROM" folders including files to a storage device.

[By Windows command line](#)

2. Run Command Prompt as **Administrator** in Windows.

<Windows 10>



Windows

2.1 Key in 'cd win' (Go to BIOS path, e.g. "E: \WIN")

```
Microsoft Windows [Version 10.0.15063]
(C) 2017 Microsoft Corporation. All right reserved.

C:\Users\user>e:

E:\>cd WIN
```

2.2a. Key in 'flash.bat' or 'flash' for 32-bit Windows and following pictures are reference only.

b. Key in 'flash_x64.bat' or 'flash_x64' for 64-bit Windows and following pictures are reference only.

```
Microsoft Windows [Version 10.0.15063]
(C) 2017 Microsoft Corporation. All right reserved.

C:\Users\user>e:

E:\>cd WIN

E:\WIN>FLASH_x64.bat
```

2.3 Press <Enter> and start to flash system BIOS and ME firmware.

```
Microsoft Windows [Version 10.0.15063]
(C) 2017 Microsoft Corporation. All right reserved.

C:\Users\user>e:

E:\>cd WIN

E:\WIN>FLASH_x64.bat

E:\WIN>AFUWINx64.exe ..\ROM\R01-A0.CAP /P /B /N /R /MEUL /CAPSULE
```

```
+-----+
|                               |
|             AMI Firmware Update Utility v5.09.02.1384             |
|             Copyright (C)2017 American Megatrends Inc. All Rights Reserved.             |
|                               |
+-----+

Reading flash ..... done
- FFS checksums ..... ok
- Check RomLayout ..... Ok .
Loading capsule to secure memory buffer ... done
Input the ME Local data into the BIOS ..... done
System is going to shutdown, are you ready? (Y/N) ... _
```

2.4 Press <Y>, system will be going to shutdown.

2.5 System will auto reboot and flash BIOS.

