


COMMERCEL UCP Flash Utility SOP


v1.1

1. Use File Explorer into UCP folder




2. Execute the *.exe file

3. If you see the UAC prompt message, press Yes





4. Wait for completion and press "Y" to restart the system




5. System Auto Power on into BIOS “Flashing...”

6. Start flash update automatically

Wait it completed





7. The system will auto reboot and then enter to OS.