Acer LCD Monitor Quick Start Guide (QSG)

Important safety instructions

Please read the following instructions carefully.

- To clean the LCD monitor screen:
 - · Turn off the LCD monitor and unplug the power cord.
 - Spray a non-solvent cleaning solution onto a rag and clean the screen gently.
- 2. Do not place the LCD monitor near a window. Exposing the monitor to rain, moisture or sunlight can severely damage
- 3. Do not apply pressure to the LCD screen. Excessive pressure may cause permanent damage to the display.
- Do not remove the cover or attempt to service this unit yourself. An authorized technician should perform servicing of any nature.
- Store the LCD monitor in a room with a temperature of -20° to 60° C (-4° to140° F). Storing the LCD monitor outside
 this range may result in permanent damage.
- 6. Immediately unplug your monitor and call an authorized technician if any of the following circumstances occur:
 - · Monitor-to-PC signal cable is frayed or damaged.
 - Liquid spills onto the LCD monitor or the monitor is exposed to rain.
 - The LCD monitor or case is damaged.

Attaching the monitor to the base

- 1. Remove the monitor from the packaging.
- 2. Attach the footstand to the base. (for selected models).
- 3. Turn clockwise to lock. Ensure that the base in locked onto the stand. (for selected models)
- 4. Secure the base to the stand by turning the screw using the intergrated tab or a suitable coin. (for selected models)

Connecting your monitor to a computer

- 1. Turn off your computer and unplug your computer's power cord.
- Connect the signal cable to the HDMI (optional) and /or DP (optional) input socket of the monitor, and the HDMI (optional) and /or DP (optional) output socket of the graphics card on the computer.
- USB Type C Cable (Optional, USB Type C input models only)
 Connect one end of the USB type C cable (optional) to your
 computer and connect the other end to your electric devices.
- 4. Connect the USB Cable(Optional)
 - Connect the cable to the fast charging USB 3.0 port (one) to charge. The normal USB 3.0 port (three) are for non-fast charging. Connect the USB 3.0/USB-B cable to port.
- Insert the monitor power cable into the power port at the back of the monitor.
- Connect the power adapter and power cord to the monitor, then to a properly grounded AC outlet.





AMD FreeSync Premium:

It can allow a AMD FreeSync Premium supported graphics source to dynamically adjust display refresh rate based on typical content frame rates for power efficient, virtually stutter free and low-latency display update.





External controls

1	Power button	Turns the monitor on/off.Blue indicates power on. Amber indicates standby/ power saving mode.		
2	Function key	Press to view Main page. Press again to enter hotkey1 function. When the Function Menu is active, press this key to view the basic information for your monitor and current input or reset the custom color settings to the factory defaults.		
3	Function key	Press to view Main page.Press again to enter hotkey2 function. When the Function Menu is active, press this button to select select scenario mode or game mode .		
4	Function key	 a. Press to view Main page.Press again to enter Input select function. b. When the Function Menu is active, this button will quit the OSD. 		
5	Function key	 a. Press to view Main page.Press again to enter next function in the Function Menu. b. The single toggle button on the backside of the Display bezel operates like a joystick. To move the cursor, simply toggle the button in four directions. Press the button to select desired option. 		

Note: Acer monitor is purposed for video and visual display of information obtained from electronic devices.

Regulations and safety notices

FCC notices

This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

CE declaration of conformity

Hereby, Acer Inc., declares that this LCD monitor is in compliance with the essential requirements and other relevant provisions of EMC Directive 2014/30/EU, Low Voltage Directive 2014/35/EU, and RoHS Directive 2011/65/EU and Directive 2009/125/EC with regard to establishing a framework for the setting of ecodesign requirements for energy-related product.

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with EMC regulations.

Notice: Peripheral devices

Only peripherals (input/output devices, terminals, printers, etc.) certified to comply with the Class B limits may be attached to this equipment. Operation with non-certified peripherals is likely to result in interference to radio and TV reception.

Caution

Changes or modifications not expressly approved by the manufacturer could void the user authority, which is granted by the Federal Communications Commission, to operate this product.

In order to prevent damage to the monitor, do not lift the monitor by its base.

Operation conditions

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Notice: Canadian users

CAN ICES-3(B)/NMB-3(B)

Disposal of waste equipment by user in private household in the European Union



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

SPECIFICATION

Size 27"W (89cm) Pixel pitch 0.233 fmm(H) x 0.233 fmm(V) Brightness 0.233 fmm(H) x 0.233 fmm(V) 0		Driving system	TFT Color LCD			
Pixel pitch						
Brightness						
Contrast						
LCD Panel Vewable angle 178" (N) 178" (V) (CR>10) (Typical) Response time Response time Insilication (S. Min.)						
Response time	I OD Desert		The state of the s			
Panel Type	LCD Panel					
H-Frequency						
DP(1.4)117PE			<u> </u>			
DP(1.4)TYPEC 2.48-270Hz(FreeSync.48-240Hz)		H-Frequency				
Display Colors		V-Frequency				
Dot Clock		Virequency				
HDMI: 2560x1440 @240Hz, Type-C: 2560x1440 @240Hz, Type-C: 2560x1440 @240Hz, Type-C: 2560x1440 @240Hz, Type-C: 2560x1440 @270Hz						
Type-C: 2560x1440 @240Hz Overclocking mode	Dot Clock					
DP 2560x1440 @270Hz				P: 2560x1440 @240Hz,		
Piug & Play	Max Resolution					
Type-C: 2560x1440 @270Hz	Wax. 1 Coolation					
DN Mode S3W(typ.)			Type-C: 2560x1440 @270Hz			
Standby Mode 0.4W(typ.)	Plug & Play		VESA DDCCI/DDC2B			
Standary Mode	Downs consum-ti	ON Mode	53W(typ.)			
Input Connector		Standby Mode	0.4W(typ.)			
HDMI (Only HDMI mode)		Off Mode	0.35W(typ.)			
USB 1/b / USB 3 / x 4 (Only USB Type C						
USB Type C (Only USB Type C model) USB R Only USB-B model) USB-B (Only USB-B model) USB-B (Only USB-B model) USB-D m	Input Connector		HDMI (Only HDMI model) USB Hub / USB3.0 x 4 (Only USB Hub Model)			
DP (Only DP Model)(Optional)	input connector		USB Type C (Only USB Type C model)			
Audio						
Audio	Input Video Signal					
Audio Audio-Output (Only Audio-Output Model) Maximum Screen Size Horizontal:596.74mm Vertical:335.66mm Power Source 100-240V-, 50/60Hz Environmental Considerations Operating Temp: 0° to 40°C Storage Temp: -20° to 60°C Operating Humidity: 20% to 80% Dimensions 614(W) x 399-519(H) x 233 (D)mm Weight (N. W.) 5.95kg Unit (net) Mechanism spec Height adjustment: 120mm Pivot: Yes Detachable foot stand: Yes Birightness Ultra-Low Latency Black Boost Aim Point Blue Light Language ACM OSD Timeout HDR Transparency Super Sharpness OSD Lock Gamma Input Color Temp. Auto Source Modes Wide Mode Color Space Hot key Assignment Controls: Functions Functions External Controls: Functions Functions Functions Functions Functions Functions Refresh Rate Num Premium Refresh Rate Num Reset	0 1					
Maximum Screen Size Horizontal:596.74mm Vertical:335.66mm Power Source 100-240V~, 50/60Hz Environmental Considerations Operating Tempp: 0° to 40°C Storage Temp: -20° to 60°C Operating Humidity: 20% to 80% Dimensions 614(W) x 399-519(H) x 233 (D)mm Weight (N. W.) Tilt: -5° to +25° Swivei: 360° Height adjustment: 120mm Pivot: Yes Detachable foot stand: Yes Brightness Contrast Ultra-Low Latency Black Boost Blue Light Language ACM OSD Timeout HDR Transparency Super Sharpness OSD Lock Gamma Color Temp. Modes Wide Mode Color Temp. Modes Wide Mode Color Space Grayscale Mode Grayscale Mode Grayscale Mode Grayscale Mode Grayscale Mode Grayscale Mode Over Drive USB 8.0 Over Orive AMD FreeSync Premium Refresh Rate Num Hower-off USB Charge Reset	<u>·</u>					
Vertical:335.66mm	Audio					
Environmental Considerations Operating Temp: 20° to 60°C Storage Temp: 20% to 60°C Operating Humidity: 20% to 80% Dimensions 614(W) x 399–519(H) x 233 (D)mm Weight (N. W.) 5.95kg Unit (net) Tilt: -5° to +25° Swivel: 360° Height adjustment: 120mm Pivot: Yes Detachable foot stand: Yes Brightness Contrast Ultra-Low Latency Blue Light ACM OSD Timeout HDR ACM OSD Timeout HDR Transparency Super Sharpness Gamma Color Temp. Modes Color Space Color Space Grayscale Mode G-axis Saturate Volume USB Port Select USB Core USB Color USB Son Over Clock AMD FreeSync Premium Refresh Rate Num Refresh Rate Num OSD Color Power-off USB Charge Reset	Maximum Screen Size					
Storage Tempi - 20° to 60°C	Power Source			100-240V~, 50/60Hz		
Storage temp: -2.0" to 60 to C	Environmental					
Dimensions						
Weight (N. W.) 5.95kg Unit (net)	Dimonsions					
Tilt: -5° to +25° Swivel: 360°						
Swivel: 360°	vveignt (iv. vv.)		<u> </u>	<u> </u>		
Pivot: Yes Detachable foot stand: Yes Brightness Contrast Black Boost Blue Light ACM HDR Transparency Super Sharpness Gamma Color Temp. Modes Wide Mode Controls: Functions Functions Functions Functions Pivot: Yes Brightness VRB Ultra-Low Latency Alm Point Language OSD Timeout Transparency Super Sharpness OSD Lock Input Color Temp. Modes Wide Mode HDK HDR Transparency Wide Mode Hot Key Assignment DDC/CI G-axis Saturate Grayscale Mode Grayscale Mode G-axis Saturate Quick Start Mode Volume USB Port Select USB 3.0 Over Drive Over Clock AMD FreeSync Premium Refresh Rate Num Refresh Rate Num Reset						
External Controls: Functions Functions Detachable foot stand: Yes Brightness Contrast Black Boost Black Boost Blue Light Language ACM OSD Timeout Transparency OSD Lock Input Color Temp. Modes Color Temp. Auto Source Modes Color Space Gamma Controls: Functions Functions Color Space Gamma Controls: Functions Color Space Gover Dive Gover Dive Gover Dive Mode Volume USB Port Select Wate Over Clock AMD FreeSync Premium Refresh Rate Num Reset	Mechanism spec		Height adjustment: 120mm			
Brightness						
Contrast Ultra-Low Latency Black Boost Aim Point Blue Light Language ACM OSD Timeout HDR Transparency Super Sharpness OSD Lock Gamma Input Color Temp. Auto Source Modes Wide Mode Controls: Functions Function		1				
Black Boost Aim Point						
ACM OSD Timeout Transparency HDR Transparency Super Sharpness OSD Lock Gamma Input Color Temp. Auto Source Modes Wide Mode Controls: Functions Functions Functions Functions Functions Functions Color Space Hot Key Assignment Grayscale Mode DDC/CI 6-axis Hue HDMI Black Level 6-axis Saturate Quick Start Mode Volume USB Port Select Mute USB 3.0 Over Drive Over Clock AMD FreeSync Premium Refresh Rate Num Reset		Functions		Aim Point		
External Controls: Functions Color Space Hot Key Assignment DDC/CI Functions Functi				Language OSD Timesurt		
Super Sharpness OSD Lock Gamma Input Color Temp. Auto Source Wide Mode Controls: Functions Functions Functions Functions Functions Color Space Wide Mode Color Space Hot Key Assignment DDC/CI 6-axis Saturate Duck Start Mode Volume USB Port Select Was Port Select USB 3.0 Over Drive Over Clock AMD FreeSync Premium Refresh Rate Num Reset			HDR			
External Color Temp. Modes Wide Mode Controls: Functions Color Space Hot Key Assignment Grayscale Mode UDC/CI Grayscale Mode UDC/CI Grayscale Mode USB Port Select USB 9.0 Over Orive Over Clock AMD FreeSync Premium Refresh Rate Num Reset Color Temp. Auto Source Note Mode USB Clarge Refresh Rate Num Reset				OSD Lock		
External Controls: Functions Functions Golor Space Grayscale Mode Grayscale Mode DDC/CI 6-axis Hue HDMI Black Level Quick Start Mode Volume USB Port Select Mute USB 3.0 Over Drive AMD FreeSync Premium Refresh Rate Num Reset						
Controls: Functions Color Space Hot Key Assignment DDC/CI	External		Modes	Wide Mode		
6-axis Hue HDMI Black Level 6-axis Saturate Quick Start Mode Volume USB Port Select Mute USB 3.0 Over Drive Over Clock AMD FreeSync Premium Reset Refresh Rate Num Reset						
6-axis Saturate Quick Start Mode Volume USB Port Select Mute USB 3.0 Over Drive Over Clock AMD FreeSync Premium Power-off USB Charge Refresh Rate Num Reset			6-axis Hue			
Mute USB 3.0 Over Drive Over Clock AMD FreeSync Premium Power-off USB Charge Refresh Rate Num Reset				Quick Start Mode		
Over Drive Over Clock AMD FreeSync Premium Power-off USB Charge Refresh Rate Num Reset						
Refresh Rate Num Reset			Over Drive	Over Clock		
*Specifications may vary depending on model, sku and/or region.			Refresh Rate Num	Reset		
*Specifications may vary depending on model, sku and/or region.						

Find manuals and other documents for your Acer product on the official Acer support website.